

Description	Stock#	Wt.
1. Ball valve w/handle, 1-1/4" NPT .....	02397	3
2. Handle, 1-1/4", ball valve .....	22532	<.5
3. Pop-up valve, 4" w/external sleeve .....	03699	4
4. Internal pop-up guide toe nipple		
• 7 cuft: 1-1/4" x 5" .....	01752	1
• 10 cuft: 1-1/4" x 6" .....	01753	1
• 20 cuft: 1-1/4" x 9-1/2" .....	01757	1.5
5. Coupling, 1-1/4" CF .....	00551	1
6. Wye 1-1/4" standard .....	01818	2
7. Metering valve, FSV w/ wye .....	02427	14
8. *Gasket, CUG coupling, (pk of 10) .....	00850	<.5
9. Inspection door assembly, 6" x 8" .....	02377	9
10. Gasket, inspection door .....	02369	<.5
11. *Umbrella, 4" bolt-on .....	02318	2
12. Muffler, exhaust .....	05068	2
13. Seat, pop-up gum rubber, std. use .....	02325	<.5
* neoprene, hot climates .....	02380	<.5
14. Nipple, 7 cuft, 1-1/4" x 13-1/2" .....	20234	2
- Nipple, 10 & 20 cuft 1-1/4" x 16-1/2" .....	21739	3
15. Elbow .....	01769	1
16. Lock pin, coupling, pk of 25 .....	11203	<.5

Description	Stock#	Wt.
<b>Note:</b> To convert to flexible pusher line, order No. 17 and 18		
17. Replacement flexible pusher line		
• 8 cuft machines 1-1/4" x 28" .....	23674	2
• 7, 10, 20, cuft machines 1-1/4" x 31" .....	23675	2
18. Adaptor, 1-1/4" flare .....	22529	1

**TLR 300 System**

(optional, components listed below)

21. Outlet valve, 1" piston .....	01967	4
22. Outlet valve, 1" diaphragm .....	03371	7
23. Inlet valve, 1-1/2" .....	01995	12
24. Abrasive trap .....	02011	4
25. RLX control handle .....	10565	1
26. Hose, 3/16" x 18" cpld .....	02454	<.5
27. Hose, 5 ft. twinline cpld .....	01952	1
28. Hose end, reusable .....	01943	<.5
29. Hose, 50 ft. twinline cpld .....	01951	8
30. Union, hose .....	01944	<.5
31. Elbow, 1/4" adaptor .....	02513	<.5

\*Optional item

**Blast Machine without Remotes 00894 Shown / Note:** For Screens & Covers — See Accessories page, Section 5, page 7.  
**Manuals:** Without Remotes, **OM 06160**; With TLR300 Remotes, **OM 22501**

