

Aluminum Size Chart for 90° Elbow Covers

ALUMINUM		90° ELBOW COVERS						
IRON PIPE SIZE	INSULATION THICKNESS							
	1/2"	1"	1 1/2"	2"	2 1/2"	3"	3 1/2"	4"
1/2"	#1	#2	#5	#8	#12	#23	#15	#25
3/4"	#1	#2	#5	#8	#12	#23	#15	#25
1"	-	#3	#6	#11	#12	#23	#15	#25
1 1/4"	-	#3	#9	#11	#18	#23	#15	#25
1 1/2"	-	#4	#9	#18	#23	#24	#25	#26
2"	-	#7	#10	#18	#20	#24	#25	#26
2 1/2"	-	#13	#16	#20	#24	#30	#26	#31
3"	-	#14	#19	#22	#24	#30	#26	#31
3 1/2"	-	#17	#21	#27	#30	#33	#31	#34
4"	-	#17	#21	#27	#30	#33	#31	#34
4 1/2"	-	#28	#27	#30	#33	#39	#34	#40
5"	-	#28	#29	#36	#38	#39	#34	#40
6"	-	#32	#35	#37	#39	#44	#45	#57
7"	-	#35	#37	#39	#44	#45	#57	#52
8"	-	#41	#42	#43	#47	#49	#52	#53
9"	-	#42	#43	#47	#49	#52	#53	GORE
10"	-	#46	#50	#51	#55	#56	Q1	GORE
11"	-	#50	#51	#55	#56	Q1	Q3	GORE
12"	-	#48	#55	#56	Q1	Q3	Q5	GORE
14"	-	GORE	GORE	Q1	Q3	Q5	Q7	GORE
15"	-	GORE	GORE	GORE	Q5	Q7	Q9	GORE
16"	-	GORE	GORE	Q5	Q7	Q9	GORE	GORE
17"	-	GORE	GORE	GORE	Q9	GORE	GORE	GORE
18"	-	GORE	GORE	Q9	GORE	GORE	GORE	GORE



To Convert Inches to millimeters: Multiply Inches x 25.4 (Example: 1" x 25.4 = 25.4 mm)